



uMetos NB-IoT SIM card installation

Guide


Pessl Instruments, GmbH

Version 1.0, 09-2017

Content

1. TOP VIEW OF THE UMETOS NB-IOT BOARD.....	2
2. INSERTING THE SIM CARD.....	3
4. GUIDE REVISIONS	4


1. Top view of the uMetos NB-IoT board



Picture 1 - Top view of the uMetos NB-IoT Rev. 2.0 board (29-0330)


2. Inserting the SIM card

uMetosNB-IoT board (29-0330) accepts Micro-SIM cards.




Picture 2 - Different SIM card sizes


Step 1: slightly push the cover down and toward the center of the uMetosNB-IoT board



Step 2: Cover should unlock and you can open it



Step 3: Insert the SIM card in correct orientation (contacts should be on the bottom side and the marking corner in the upper left position)



Step 4: close the cover and push it gently outward so the cover gets locked



3. Guide revisions

GUIDE VERSION	MODIFICATIONS
1.00	- First release of the document.